


## JTD-128NPP5U



JTD-128NPP5U



5U PATCH PANEL, TYPE N, 128X

??: ????  
[?????????](#)

??  
??-6000??50 ??N(f) ? N(f) ?????????? 19 ?????????????/????????? RoHS ??

- DC-6000 MHz
- 50 ?, N(f) to N(f) Adapters
- Installs In Std 19" Rack Space
- Manage Cable/Component Interconnects
- RoHS Compliant

| FREQUE  | Z (?) | INSERTIO | VSWR   |
|---------|-------|----------|--------|
| DC-6000 | 50    | 1.0      | 1.10:1 |